

QUICK-LOCK Tankring (SUZUKI B-King ('08 -), 3 Schrauben)  
QUICK-LOCK Tankring (SUZUKI B-King ('08 -), 3 Screws)

INFORMATION

**Bitte beachten Sie unbedingt die folgenden Hinweise:**

Der Abstand zwischen den Rasthaken muß mindestens 70 mm betragen, ggf. die Rasthaken beidseitig nach Außen drücken.

Beim Verschrauben des Tankrings auf den Tank auf Widerstand achten, da bei zuviel Druck der Tankring und Tankdeckelring beschädigt werden kann.

**Achtung:** SW-MOTECH übernimmt keine Haftung für Schäden, die durch eine unsachgemäße Montage verursacht wurden. Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

**Please pay attention to the following information:**

The space between the hook-ends must be at least 70 mm wide, if necessary push the hook-ends outward while tightening so the resulting distance between them is at least 70 mm.


Be careful when mounting the tankring. Using too much pressure to tighten the screws can damage the tankring and fuel tank cap.

**Attention:** SW-MOTECH accepts no liability for damages caused by improper mounting.

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.


**Anzugsmoment**

M5 4,5 Nm



**Locked Torque**

M5 4,5 Nm



1

Tankring  
Tankring



TRT.00.475.001K1

Anzahl/ Pcs. 1

3

Innensechskantschraube  
Hexagon Socket Screw



M5 x 12 DIN 912

Anzahl/ Pcs. 4

2

Montagering  
Mounting Ring



TRT.05.640.029 00

Anzahl/ Pcs. 1

4

Innensechskantschraube  
Hexagon Socket Screw



M5 x 20 DIN 912

Anzahl/ Pcs. 3

SW-MOTECH GmbH & Co. KG  
Ernteweg 8/10  
35282 Rauschenberg  
Germany

Tel. +49 (0) 64 25/8 16 8-00  
Fax +49 (0) 64 25/8 16 8-10

info@sw-motech.com  
www.sw-motech.com

Technische Änderungen vorbehalten. Irrtümer ausgenommen.  
Subject to change. Not responsible for typos. Subject to change. Not responsible for typos.

Fahrtrichtung  
Driving direction

